


FRONT VIEW RW-10



FRONT VIEW RW-10

<u>ITEM</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
1	1	Tank Handle	RPO3482
2	1	Jack Shaft	RMB2005-2
3	1	Pillow Block Bearing	RPO3329
4	1	300 Gal. Fiberglass Tank	RMC1003
5	2	Seat	RPO3159
6	1	Jack Shaft Stand	RMC1500
7	1	2 Groove Sheave	RMB1102
8	1	Clutch Idler Assy.	RMC2508
9	1	S & R Control Valve Assy.	RMC1542
10	2	Seat Mount Assy.	RMB2700
11	2	Seat Spring	RPO3160
12	1	Steering Wheel	RMB1148
13	1	Emergency Brake Assy.	RPO3191
14	1	Master Cylinder	RPO3478
15	1	Platform Assy.	RMC2500
16	1	Steering Column	RMB2045
17	1	Shift Lever Assy.	RMB1171
18	1	Power Steering Head	RPO3479
19	1	Transmission Mounting Plate	RMC1014
20	1	Clutch Hold In Spring	RPO3146
21	1	Clutch Pivot Assy.	RMC1543
22	1	Clutch Idler Pivot	RMB2703
23	1	Transmission	RPO3420
24	2	Leaf Spring Hanger	RMB1372
25	2	Leaf Spring Assy.	RMB1376-7
26	2	Shackle	RMB1371
27	1	Drive Belt	RPO3384
28	2	Front Tire	RPO3453
29	2	Wheel Center	RMB1314
30	1	Front Axle	RPO3480
31	1	Tow Bar Assy.	RMC1054
32	1	Hydraulic Steering Cylinder	RMC1009